



REPLACEMENT PARTS

MODEL NO.
71202

CAPACITY
2 TON

DESCRIPTION
FLOOR SERVICE JACK



INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Top Handle Half	218601	1
2	Bottom Handle Half	218602	1
3	5/16" Flat Washer	2071	2
4	5/16" Internal Star Lockwasher	2120	1
5	5/16" - 18 x 3/4" Long Hex. Head Bolt	3151	1
6	Handle Base	218603	1
7	3/8" - 16 x 3/4" Long Hex. Head Bolt	3053	1
8	3/8" Internal Star Lockwasher	2122	1
9	Handle Base Pump Roller	218604	1
10	Metric Shoulder Bolt	218606	1
11	Handle Assembly Complete	218625	1
12	5/16" Split Medium Lockwasher	1034	1
13	Nyloc Metric Nut	218607	1
14	Handle Base Pivot Bolt	218608	2
15	3/4" Internal Star Lockwasher	2123	6
16	Hydraulic Block Assembly Complete	218605	1
17	Hydraulic Block	218609	1
18	Reservoir End Cap	218611	2
*19	O-Ring for End Cap	218612	2
20	Screen Filter	218613	1
21	Port Screw Plug	218614	1
22	Vented Fill Plug	218615	1
*23	O-Ring for Fill Plug	218616	1
24	Overload Adjustment Screw	218617	1
*25	Overload O-Ring	218618	1
26	Overload Spring	218619	1
27	Overload Spring End Cap	218621	1
*28	Overload 3/16" Dia. Checkball	9007	1
29	Valve Cap Screw	218622	1
*30	Copper Washer	218623	1
31	Separator Spring (Large)	218624	1
*32	Injector port 5/16" Dia. Checkball	9005	1
33	Separator Spring (Small)	218626	1
*34	Suction Port 7/32" Dia. Checkball	9017	1
35	Release Valve Assembly	218620	1
*36	Release Valve O-Ring	218627	1
*37	Release Valve 1/4" Dia. Checkball	9004	1
38	Pump Housing	218628	1
*39	Pump O-Ring	218629	2
*40	Pump Backup Ring	218631	1
41	Pump Piston	218632	1
42	Pump Spring	218633	1
43	Pump Spring Cap	218634	1
44	3/4" External Retaining Ring	12196	5
45	Cylinder	218636	1
46	Ram	218637	1

INDEX NO.	DESCRIPTION	PART NO.	QTY.
47	Ram Retaining Ring	218638	1
48	Ram Backup Washer	218639	1
*49	Ram U-Cup	218641	1
*50	Ram Backup Ring	218642	1
51	Ram Bearing	218643	1
52	Cylinder Bearing	218644	1
53	1/2" - 13 X 1" Long Hex. Head Bolt	11104	4
54	1/2" Internal Star Lockwasher	2126	8
55	Caster Wheel Assembly	218610	2
56	Handle Base Assembly Complete	218630	1
57	3/4" - 10 Hex. Nut for Caster Assy.	1012	2
58	3/8" - 15 x 1 1/4" Long Allen Socket Cap Screw	3118	1
59	3/8" - 16 Hexagonal Nut	1006	1
60	3/8" - 16 Nyloc Hexagonal Nut	1054	1
61	Ram Retraction Spring	218646	1
62	3/16" Dia. x 1 1/4" Long Expansion Pin	7058	1
63	Trunion	218647	1
64	Left Side Plate Assembly Complete	218665	1
65	Trunion Arm	218648	2
66	Trunion Shoulder Bolt	218549	2
67	Right Side Plate Assembly Complete	218670	1
68	3/4" - 16 UNF Jam Nut for Trunion Bolt	1104	2
69	Elevator Arm	218651	1
70	Zerk Grease Fitting	218652	1
71	Elevator Arm Pivot Pin	218653	1
72	7/8" Internal Star Lockwasher	2127	4
73	7/8" - 9 Hexagonal Jam Nut	1106	4
74	Cylinder Support Bracket	218654	1
75	Set Screw	218656	1
76	Support Bracket Shaft	218657	1
77	Elevator Arm Stop Pin	218671	2
78	1/2" - 13 Hexagonal Nut	1007	4
79	Guide Arm	218658	2
80	Guide Arm Shoulder Bolt	218659	2
81	Stop Pin Bolt	218672	2
82	Front Axle Washer	218668	2
83	Pin (Long)	218661	1
84	Pin (Short)	218662	1
85	1/2" External Retaining Ring	12195	4
86	Saddle Base	218663	1
87	Saddle	218664	1
88	1-3/16" External Retaining Ring	1204	1
89	Front Wheel	218666	2
90	Front Axle	218667	1
91	Caster Washer	218673	2
92	Cylinder Copper Washer	218674	1

*Designates those parts included in repair kit 218860