



REPLACEMENT PARTS

MODEL NO.
71230

CAPACITY
2 1/4 TON

DESCRIPTION
HYDRAULIC FLOOR JACK



INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Release valve assy.	218505	1
2	Release valve	218501	1
*3	5/16" dia. checkball	9005	1
4	Copper washer	218502	2
5	Guide washer	218503	1
6	Valve port screw	218504	1
*7	Back-up ring	218506	1
*8	O-ring	218507	1
*9	3/8" dia. checkball	9008	1
*10	1/4" dia. checkball	9004	2
11	Overload cover screw	218508	1
*12	Rubber packing	218509	1
*13	Rubber cover	218511	1
14	Overload adjustment screw	218512	1
15	Overload screw	218513	1
16	Overload valve	218514	1
17	Pump piston	218516	1
*18	Oil seal	218517	1
*19	Back-up ring	218518	1
*20	O-ring	218519	1
21	Oil fill plug	218521	1
22	Oil block	218522	1
23	Snap ring	218523	1
*24	U-cup seal	218524	1
*25	Back-up ring	218526	1
26	Ram bearing	218527	1
27	Filter	218528	1
28	By-pass spring	218529	1
29	Spring retainer	218531	1
30	Valve pin	218532	1
31	Limit pin	218533	1
32	Ram	218534	1
*33	O-ring	218536	1
34	Cylinder nut	218537	1
*35	O-ring	218538	1
*36	Oil seal	218539	1
37	Hydraulic block assy. complete	218510	1
38	Handle base	218541	1
39	Handle retainer screw	218542	1
40	Handle release stem	218543	1
41	Flat gear	218544	1
42	Nut	218546	1

INDEX NO.	DESCRIPTION	PART NO.	QTY.
43	Cotter pin	218547	1
44	Handle torsion spring	218548	1
45	Pump piston pin	218549	1
46	Elevator arm assy.	218515	1
47	Arm pivot pin	218551	1
48	Grease zerk fitting	218552	2
49	Saddle	218553	1
50	Guide arm	218554	2
51	Saddle base pin	218556	1
52	Saddle base	218557	1
53	Retainer ring	218558	2
54	Guide arm bolt	218559	2
55	Guide arm pin	218561	1
56	Spacer pin	218562	1
57	Front wheel	218563	2
58	Wheel washer	218564	2
59	Wheel retaining ring	218566	2
60	Chassis assy.	218520	1
61	Lockwasher	218567	4
62	Nut	218568	4
63	Ram retraction spring	218569	1
64	Pivot pin washer	218571	2
65	Pivot pin nut	218572	2
66	Caster wheel assy.	218525	2
67	Caster lockwasher	218573	2
68	Caster nut	218574	2
69	Washer	218576	2
70	Mounting bolt	218577	2
71	Handle base washer	218578	2
72	Left handle base bolt	218579	1
73	Right handle base bolt	218581	1
74	Spacer bolt	218582	1
75	Kick plate	218583	1
76	Kick plate washer	218584	2
77	Kick plate screw	218586	2
78	Handle assy. complete	218530	1
79	Handle grip	218587	1
80	Upper handle	218588	1
81	Lower handle	218589	1
82	Handle screw	218591	1
83	Trunion cotter pin	218592	1
	Repair kit	218300	

* = asterisks indicate those parts included in repair kit 218300