



REPLACEMENT PARTS

MODEL NO.
72300

CAPACITY
1/2 TON

DESCRIPTION
SINGLE STAGE UNDERHOIST TRANSMISSION JACK



INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Screw	3072	4
2	Washer	2017	4
3	Containing angle	282231	4
4	Nut	282073	6
5	Washer	282066	2
6	Flange nut	282077	2
7	Chain tension adjuster	282078	2
8	Clevis bolt	282168	2
9	Clevis	282167	2
10	Eye bolt	282069	2
11	Cotter pin	7021	3
12	Universal saddle	282184	1
13	Saddle tilt pin	228233	1
14	Castle nut	1042	2
15	Washer	282098	2
16	Anchor trunion	282102	2
17	Chain	282067	2
18	Bronze bushing	282101	2
19	Retaining ring	12124	2
20	Saddle tilt pin	282087	1
21	Pivot base	282099	1
22	Threaded trunion	282089	2
23	Retaining ring	12124	4
24	Tilt screw	282096	2
25	Expansion pin	7027	2
26	Large handle	282186	1
27	Small handle	282187	1
28	Nut	282058	1
29	Saddle base	282088	1
30	Adapter	282188	1
31	Screw	282162	1
32	Snap ring	605011	1
33	Upper bearing	605013	2
*34	O-ring	605012	1
35	Sleeve	605032	1

INDEX NO.	DESCRIPTION	PART NO.	QTY.
36	Ram	605033	1
37	Limit pin	605024	1
38	Valve pin	605022	1
39	1/4" dia. check ball	9004	1
40	Spring	4007	1
41	Retainer	2005	1
42	(A) Ram bearing	605017	1
*43	Backup ring	605018	1
*44	O-ring	605019	1
45	(B) Ram bearing	605021	1
46	Handle grip	282189	1
47	Handle	282191	1
48	Lever linkage assembly	605105	1
49	Pin	7006	1
50	Retaining ring	12003	2
51	Pin	7007	1
52	Washer	2071	1
53	Bolt	11073	1
*54	Fill plug	11001	1
55	Pump piston	605109	1
*56	Backup ring	605028	1
*57	O-ring	605027	1
58	Jack body assembly	282360	1
*59	O-ring	12001	1
60	Release valve	602056	1
*61	5/16" dia. checkball	9005	1
*62	7/32" dia. checkball	9002	1
63	1/2" - 13 hex jam nut	1094	8
64	Lockwashers	282254	8
65	Leg	282251	2
66	Caster nut	282252	4
67	Caster washer	282334	4
68	Leg bolt	282253	8
69	Caster	282255	4

* indicates those parts included in repair kit 605600