



INDEX NO	DESCRIPTION	PART NO.	REQ'D NO
1	Jack Base	N/A	1
*2	3/16" Check Ball	9007	3
3	Spring	612176	1
4	Washer	612177	1
5	Set Screw	612178	1
*6	5/16" Check Ball	9005	1
*7	O-Ring	612179	1
8	Release Valve	612181	1
9	Pump Assembly	612182	1
10	Set Screw	612183	2
11	Set Screw	162184	1
12	Washer	612186	1
13	Ram Bearing	612187	1
*14	Fill Plug	612188	1
*15	O-Ring	612189	1
16	Reservoir	612190	1
17	Ram	612191	1
18	Pin	612192	1
*19	7/32" Check Ball	9001	2
20	Pin	612193	1
21	Fitting	612194	1
22	Spring	612196	1
*23	Washer	612197	1
*24	Backup Ring	612198	1
*25	O-Ring	612199	1
26	Ram Bearing	612201	1
27	C-Ring	612202	1
28	Primary Cylinder	612203	1
29	Spring Buckle	612204	1
30	Extension Screw w/Bushing	612205	1
*31	O-Ring	612206	1
32	Primary Cylinder Nut	612207	1
33	Handle Tube A - Lower	612208	1
34	Handle Tube B - Upper	612209	1
35	Air Motor w/Air Valve Assy	612210	1
36	See Item 20		
37	90 degree 1/8" Elbow	612211	2
38	Steel Hose	612212	1
39	Spring	612213	2
40	Ram Steel Washer	612214	1
41	High/Low Check Valve	612216	1
*42	Seal Ring	612217	1
43	Cover	612218	1
44	Nut	612219	1
*45	Plunger	612221	1
*46	O-Ring	612222	1
*47	O-Ring	612223	1
48	Backup Ring	612224	1
49	Air Valve	220140	1
50	Air Hose	220150	1

\*Items in Repair Kit 612200

**REPLACEMENT  
PARTS**

**MODEL NO.  
76312A**

**CAPACITY  
12 TON**

**DESCRIPTION  
Air Operated Hydraulic Bottle Jack**

