

REPLACEMENT PARTS	MODEL NO.	CAPACITY	DESCRIPTION
	72450A	1/2 TON	AIR/HYDRAULIC TELESCOPIC TRANSMISSION JACK

norco®

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
°1	Wiper Ring	282401	1
°2	Seal	282402	1
3	Secondary Cylinder Nut	282403	1
4	Checkball	282404	1
5	Set Screw	282406	1
°6	O-ring	282407	1
°7	Seal	282408	1
°8	Seal	282409	1
9	Primary Cylinder Nut	282411	1
10	Air Valve	282412	1
11	Pin	282413	1
°12	O-ring	282414	2
13	Air Valve Body	282416	1
°14	Seal	282417	4
15	Pipe Elbow	282418	1
16	Vent Body	282419	1
17	Air Filter	282421	1
°18	Seal	282422	1
19	Valve Holder	282423	1
20	Valve	282424	1
21	Valve Seat	282426	1
22	Washer	282427	1
23	End Fitting	282428	1
24	Reservoir Fill Plug	282429	1
25	Allen Socket Button Screw	282431	4
°26	O-ring	282432	2
°27	Seal	282433	1
°28	O-ring	282891	1
29	Secondary Ram Assembly	282892	1
30			
31			
32	Primary Ram Assembly	282893	1
			1
			1
°35	Backup Ring	282442	1
°36	O-ring Seal	282443	1
37	Ring	282444	1
38	Fitting	282446	1
°39	Checkball	282447	1
40	Valve Pin	282448	1
41	Protrusion	282449	1
42	Sleeve	282451	1
43	Primary Cylinder	282894	1
44	Pump Block	282453	1
45	Reservoir Tube	282896	1

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
49	Rubber Shield	282458	1
°50	O-ring	282459	1
51	Hydraulic Base	282461	1
52	Screw	282462	4
53	Flat Washer	282463	4
54	Lock Washer	282464	4
55	Hex Head Screw	282466	4
56	Washer	282467	8
57	Allen Socket Cap Screw	282468	8
58	Leg Assembly	282830	4
59	Elbow Fitting	282557	2
60	Hose Assembly	282895	1
61	Fitting	282473	1
62	Retaining Ring	282474	2
63	Pivot Pin	282476	1
64	Allen Socket Cap Screw	282477	2
65	Washer	282478	2
66	Pressure Plate	282479	1
67	Sponge Filter	282481	1
68	Allen Socket Cap Screw	282482	2
69	Pump Manifold	282483	1
*70	O-ring	282484	1
71	Release Valve	282486	1
*72	O-ring	282487	1
73	Spring	282488	1
74	Valve Guide	282489	1
*75	Backup Ring	282491	2
*76	O-ring	282492	2
77	Pin	282493	1
78	Valve Stem	282494	1
*79	Checkball	282496	1
80	Spring	282497	1
*81	Backup Ring	282498	1
82	Housing	282499	1
83	Spring	282501	1
*84	Checkball	282502	2
85	Pump Pedal	282472	1
86	Allen Socket Cap Screw	282504	4
87	Allen Socket Cap Screw	282506	1
*88	O-ring	282507	2
89	Housing	282508	1
90	Screen	282509	1

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
91	Retaining Ring	282511	1
92	Allen Socket Cap Screw	282512	8
93	Filter	282513	1
94	Disc	282514	1
95	Air Pump Body	282503	1
*96	O-ring	282517	1
*97	Backup Ring	282518	1
*98	O-ring	282519	1
99	Bottom Bolt Fitting	282521	1
*100	U-cup Seal	282522	1
101	Spring Guide	282523	1
102	Screw	282524	4
103	Air Pump Spring	282526	1
104	Hydraulic Piston	282527	1
105	Spring/Piston Retainer	282528	1
*106	O-ring	282529	2
*107	Quad Ring	282531	2
108	Front Air Piston Half	282532	1
*109	O-ring	282533	1
110	Shuttle Valve	282534	1
111	Rear Air Piston Half	282536	1
*112	Rubber Stopper	282537	1
113	Screw	282538	3
114	Air Cylinder	282539	1
*115	O-ring	282541	1
116	Air Cylinder End Cap	282542	1
*117	O-ring	282838	2
118	Allen Socket Cap Screw	282544	6
119	Elbow Fitting	282546	1
120	Filter Screen	282547	1
121	Optional Male Air Disconnect	282548	1
122	Pipe & Fitting Assembly	282410	1
*123	O-ring	282549	2
124	Pump Stem Assembly	282845	1
*125	O-ring	282552	1
126	Spring	282553	1
127	Allen Socket Set Screw	282554	1
128	Pump Support Bracket	282556	1
129	Spring	282899	1
130	Locking Caster Assembly	282260	2
131	Complete Pump Assembly	282825	1
132	Caster Assembly	282245	2
133	Complete Saddle Assembly	282435	1
134	Shoulder Bolt	282391	4
135	Pin	282392	4

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
136	Washer	282561	4
137	Containing Angle Assembly	282440	4
138	Washer	282562	8
139	Bronze Bushing	282563	4
140	Knob	282564	4
141	Retainer	282566	4
142	Caster Nut	1013	4
143	Nut	282568	8
144	Washer	282569	8
145	Flange Nut	282571	4
146	Chain Tensioner Adjuster	282572	2
147	Expansion Pin	282573	1
148	Cotter Pin	282586	2
149	Universal Saddle	282576	1
150	Saddle Tilt Pin	282577	1
151	Eye Bolt	282578	4
152	Clevis	282579	4
153	Clevis Bolt	282581	4
154	Chain	282582	2
155	Cotter Pin	282583	2
156	Castle Nut	282584	2
157	Retaining Ring	282586	2
158	Saddle Tilt Pin	282587	1
159	Pivot Base	282588	1
160	Retaining Ring	282589	8
161	Anchor Trunion	282591	2
162	Threaded Trunion	282592	2
163	Bronze Washer	282593	4
164	Saddle Base	282386	1
165	Bolt	282372	1
166A	Tilt Screw (short)	282595	1
166B	Tilt Screw (long)	282597	1
167	Expansion Pin	282598	2
168	Tilt Handle	282559	2
169	Lockwasher	2007	4
171	Washer	282561	4
172	Shoulder Bolt Assembly	282558A	1
	° Cylinder/Ram Seal Kit	282425	1
	* Pump Kit	282885	1

° *The dot designates those parts included in the Cylinder/Ram Seal Kit Part No. 282425*

* *The asterisk designates those parts included in the Pump Seal Kit Part No. 282885*