REPLACEMENT PARTS

MODEL NO. 72700

CAPACITY 1 TON

DESCRIPTION UNDERHOIST TRUCK TRANSMISSION JACK



NORCO

INDEX NO.	DESCRIPTION	PART NO.	QTY.
1	Fore/aft extension assy.	229049	2
2	Extension arms	229051	4
3	Lock screws	229052	6
4	Mounting bolts	229053	4
5	Universal adaptor	229048	1
6	Eye bolt	229056	1
7	Chain w/hook	229058	1
8	Wing nut	229057	4
9	Hydraulic block housing	229705	1
10	Saddle plate	229728	1
11	Anchor trunion	229729	1
12	Saddle base	229731	1
13	Saddle tilt pin	229732	1
14	Trunion	229733	1
15	Side tilt pin	229734	1
16	Trunion	229736	1
17	Threaded trunion	229737	1
18	Tilt screw	229738	2
19	Adaptor	229730	1
20	Tilt screw knob	229741	2
21	Flat washer	2078	4
22	Collar	229742	4
23	Bearing	229743	4
24	Retainer (1.375 dia. shaft)	229744	4
25	Retainer (.625 dia. shaft)	229746	2
26	Retainer (.750 dia. shaft)	229747	2
27	Retainer (1.125 dia. shaft)	229748	4
28	Set screw	229749	4
29	Expansion pin	229751	2
30	Leg	229710	2
31	Brace	229711	4
32	Brace collar	229712	2
33	Caster	229713	4
34	Bolt, caster	229714	16
35	Bolt, strut	11156	8
36	Washer	2017	8
37	Nut	1007	8
38	Leg mounting bolt	229719	8
39	Leg mounting washer	229721	8
40	Washer, caster	229722	8
41	Nut, caster	229723	8
42	Pump pedal	282221	1
43	Pedal pivot pin	282222	1
44	Pedal bearing pin	282223	1
45	Spacer	282224	1

INDEX NO.	DESCRIPTION	PART NO.	QTY.
46	Retaining ring	282219	4
47	Pump piston	229702	1
48	Pump spring	282229	1
49	Spring guide	229701	1
*50	Oil wiper seal	229703	1
*51	Back-up ring	229704	1
*52	O-ring	229706	1
53	Fill plug	229707	1
54	Strap (plastic)	229708	1
55	Vented fill plug	229709	1
56	Overload screw	282248	1
*57	O-ring	282247	1
58	Overload spring	282246	1
59	Ball retainer	282244	1
60	Check ball, 3/16" dia.	9007	1
61	Check ball, 1/4" dia.	9004	4
62	1/4 - 20 x 5/16 skt., allen	3142	4
63	Valve cover screw	282239	2
*64	Copper washer	282241	2
65	Valve spring	282243	2
66	5/16" dia. check ball	9005	2
67	Release pedal	282256	1
68	Release pivot pin	282231	2
69	Pedal support pin	282233	1
70	Retaining ring	282232	2
71	Release valve shaft	282249	1
*72	Release O-ring	282234	1
73	Release housing	282236	1
74	Release spring	282237	2
75	Release nut	282238	1
76	Release valve assy.	282250	1
*77	Copper washer	282241	1
78	Ram	229724	1
*79	Split guide ring	229726	1
*80	Back-up	229727	1
*81	O-ring	229752	1
*82	Oil seal	229756	1
*83	Pressure seal	229757	1
84	Cylinder nut	229753	1
*85	O-ring	229754	1
86	Hydraulic assy. complete	229715	1
87	Bolt	11009	2
88	Lock washer	2007	2
89	Nut	1006	2
90	Vent plug	229758	1

* 229750 includes parts for seal kit