

INDEX NO.	DESCRIPTION	PART NO.	REQ'D NO
1	Base Assembly	N/A	1
2	Wheel	291201	2
3	Cotter Pin	291202	2
4	Washer - Wheel	291203	4
5	Saddle Adjustment Pin - Short	291230	1
6	Ram	291206	1
7	Serrated Saddle Column	291225	1
8	Cylinder Wear Band	291208	1
9	Extension AdjustmentPin - Long	291209	2
10	U-Cup Seal	291211	1
11	Seal Plate	291212	1
12	Seal Bolt	291213	1
13	Extension Column	291214	1
14	Hex Nut - Cylinder Plate	291216	6
15	Cylinder Plate	291217	1
16	Handle Grip	291218	2
17	Handle Assembly	291210	1
18	Hex Nut - Handle Base	291219	1
19	Air Hose	291221	1
20	Washer - Cylinder Plate	45100876	1
21	New Style Air Valve Assembly	45100875	1
22	Ram Wear Band	291224	1
23	Steel Washer	291223	1
24	O-Ring	291226	1
25	Lock Washer - Handle Base	291227	1
26	Bolt - Handle Base	291228	1

05/01/26

REPLACEMENT PARTS	MODEL NO.	CAPACITY	DESCRIPTION
	82990B	10 TON	PORTABLE AIR LIFT JACK

norco®